



User Manual

FIE1N Mini Type VFD User Manual



Contents

Safety Information and Precautions	2
1. Product Information	3
1.1 Nameplate and Designation Rule	3
1.2 General Specifications	4
1.3 Environment	5
2. Wiring	6
2.1 Typical System Connection	6
2.2 Terminal Description	7
2.3 Remove the EMC and VDR Screws	8
3. Operating Panel	9
3.1 Get Familiar with Operating Panel	9
4. Quick Setup	11
4.1 Setup Flowchart	11
5. Parameter Table	17
5.1 Introduction	17
5.2 Standard Parameters	17
5.3 Monitoring Function Code	30
6. Troubleshooting	31
6.1 AC Drive Performance Fine Tuning	31
6.2 Fault Codes and Troubleshooting	32
6.3 Symptoms and Diagnostics	35
Revision History	36

Safety Information and Precautions

This guide is packaged together with the product for FIE1N AC Drive. It contains basic information for quick start of the drive. For safety and more information, please refer to the FIE1N AC Drive User Manual, which can be downloaded on website: www.vtdrive.com

■ Electrical Safety

Extreme care must be taken at all times when working with the AC Drive or within the area of the AC Drive. The voltages used in the AC Drive can cause severe electrical shock or burns and is potentially lethal. Only authorized and qualified personnel should be allowed to work on AC Drives.

■ Machine/System Design and Safety of Personnel

Machine/system design, installation, commissioning startups and maintenance must be carried out by personnel who have the necessary training and experience. They must read this safety information and the contents of this manual. If incorrectly installed, the AC Drive may present a safety hazard.

The AC Drive uses high voltages and currents (including DC), carries a high level of stored electrical energy in the DC bus capacitors even after power OFF. These high voltages are potentially lethal.

The AC Drive is NOT intended to be used for safety related applications/functions. The electronic "STOP & START" control circuits within the AC Drive must not be relied upon for the safety of personnel. Such control circuits do not isolate mains power voltages from the output of the AC Drive. The mains power supply must be disconnected by an electrical safety isolation device before accessing the internal parts of the AC Drive.

Safety risk assessments of the machine or process system which uses an AC Drive must be undertaken by the user and/or by their systems integrator/designer. In particular, the safety assessment/design must take into consideration the consequences of the AC Drive failing or tripping out during normal operation and whether this leads to a safe stop position without damaging machine, adjacent equipment and machine operators/users. This responsibility lies with the user or their machine/process system integrator.

The system integrator/designer must ensure the complete system is safe and designed according to the relevant safety standards. VTdrive Technology and Authorized Distributors can provide recommendations related to the AC drive to ensure long term safe operation.

■ Electrical Installation - Safety

Electrical shock risk is always present within an AC Drive including the output cable leading to the motor terminals. Where dynamic brake resistors are fitted external to the AC Drive, care must be taken with regards to live contact with the brake resistors, terminals which are at high DC voltage and potentially lethal. Cables from the AC Drive to the dynamic brake resistors should be double insulated as DC voltages are typically 300 to 400 VDC.

Mains power supply isolation switch should be fitted to the AC Drive. The mains power supply must be disconnected via the isolation switch before any cover of the AC Drive can be removed or before any servicing work is undertaken. Stored charge in the DC bus capacitors of the PWM inverter is potentially lethal after the AC supply has been disconnected. The AC supply must be isolated at least 10 minutes before any work can be undertaken as the stored charge will have been discharged through the internal bleed resistor fitted across the DC bus capacitors.

Whenever possible, it is good practice to check the DC bus voltage with a VDC meter before accessing the inverter bridge. Where the AC Drive input is connected to the mains supply with a plug and socket, then upon disconnecting the plug and socket, be aware that the plug pins may be exposed and internally connected to the DC bus capacitors (via the internal bridge rectifier in reversed bias). Wait 10 minutes to allow stored charge in the DC bus capacitors to be dissipated by the bleed resistors before commencing work on the AC Drive.

■ Electrical Shock Hazard

Ensure the protective earthing conductor complies with technical standards and local safety regulations. Because the leakage current exceeds 3.5 mA in all models, IEC 61800-5-1 states that either the power supply must be automatically disconnected in case of discontinuity of the protective earthing conductor or a protective earthing conductor with a cross-section of at least 10 mm² (Cu) or 16 mm² (Al) must be used. Or use two PE wires and each wire must satisfy the IEC requirements independently. Failure to comply may result in death or serious injury.

When using an earth leakage circuit breaker, use a residual current operated protective device (RCD) of type B (breaker which can detect both AC and DC). Leakage current can cause unprotected components to operate incorrectly. If this is a problem, lower the carrier frequency, replace the components in question with parts protected against harmonic current, or increase the sensitivity/ampereage of the leakage breaker to at least 100 mA per drive.

Factors in determining leakage current:


- Size of the AC drive
- AC drive carrier frequency
- Motor cable type and length
- EMI/RFI filter


1. Product Information

1.1 Nameplate and Designation Rule



Nameplate

AC drive model →	MODEL: FWI-FIE1N-2d2	CE
Rated input →	INPUT: 1PH AC 200-240V 27.0A 50Hz/60Hz	
Rated output →	OUTPUT: 3PH AC 0-240V 11.0A 0-500Hz 2.2kW	
S/N code →	S/N: Serial Number	
		
Manufacturer —	VTDRIVE TECHNOLOGY LIMITED www.vtdrive.com	




1.2 General Specifications

Voltage class		200 to 240VAC				
Model: FIE1N***B ⁽¹⁾		04	075	15	22	
Dimension ⁽²⁾	Height	[H]: 180 mm				
	Width	[W]: 75 mm				
	Depth	[D]: 145 mm				
Mounting Hole, [mm]		Φ5.0				
Drive Input	Rated Input voltage	1 PH, 200 to 240 VAC , -15% to +10%				
	Rated input current, [A]	65	110	180	270	
	Rated input frequency	50/60 Hz, ±5%				
	Power capacity, [kVA]	17	30	48	71	
Drive Output	Applicable motor	[kW]	04	075	15	22
		[HP]	05	1	2	3
	Output current, [A]	26	46	80	110	
	Default carrier frequency, [kHz]	6	6	6	6	
	Overload capacity	150% for 60 Sec				
	Max output voltage	3 PH, 0 to 240 VAC				
	Max output frequency	50 to 500 Hz				
Braking Resistor	Recommended power, [W]	80	80	100	100	
	Recommended resistance, min. [Ω]	200	150	100	70	
Weight, [kg]		11				

Note

(1): "B" denotes build-in brake function(2):

The dimensions are shown as below:




1.3 Environment

Altitude	Below 1000 m, 1% derating current per 100 m at 1000 to 3000 m Max 3000 m
Storage Temperature	-20°C to +60°C
Operating Temperature	-10°C to +40°C. 1.5% derating current per 1°C at 40°C to 50°C. Max. 50°C.
Max Humidity	≤ 95% RH, no-condensing
Vibration	≤ 5.9 g/s ² (06 g)
Running Environment	PD2
Power Supply System	TT/TN
	IT (Remove the screws of VDR and EMC filter according to section 2.3.)
Enclosure	IP20

2 Wiring

21 Typical System Connection




Note

For the DI terminals, low level is valid and valid level is < 5 V, input resistance is 3.6 K, DI1 to DI3 satisfies 100 Hz frequency input, and DI4 satisfies 20 kHz frequency input. The requirement of pulse duty cycle is 30% to 70%.

22 Terminal Description

■ Terminals of Main Circuit



Terminal	Terminal Name	Description
L1, L2	Single-phase supply input	Connect to the single-phase AC power supply
BR, (+)	Braking resistor connection	Connected to external braking resistor
U, V, W	Output terminals	Connect to a three-phase motor
⊕	Ground (PE)	Grounding connection

■ Terminals of Main Control Board

The diagram shows a terminal block with two rows of terminals. The top row contains terminals labeled D11, D12, D13, D14, COM, AI, AO, 10V, GND, 485+, 485-, IA, and TC. The bottom row contains terminals labeled D11, D12, D13, D14, COM, AI, AO, 10V, GND, 485+, 485-, IA, and TC. Each terminal is represented by a screw head with a cross-shaped slot.


DIP switch
Default value: 1: OFF, 2: OFF, 3: OFF

	Current input		Matching RS485 terminal resistor
	Voltage input		Not matching RS485 terminal resistor

Terminal	Terminal Name	Description
+10V-GND	+10 VDC power supply	Provides +10V power supply to an external unit Generally used to supply an external potentiometer of 1 to 5 kΩ. Max output current: 10 mA
AI-GND	Analog input	Either a voltage or a current input, determined by jumper J9; Input voltage range: 0 to 10 VDC; Input current range: 0 to 20 mA; Resolution: 12 bits Correction accuracy: 0.5% Response time: < 8 ms
DI1-COM	Digital input	Low level valid; Valid level < 5 V; Frequency < 100 HZ Input resistance: 4 kΩ
DI2-COM		
DI3-COM		
DI4-COM	High-speed pulse input	High-speed pulse input, supporting a maximum of 20 kHz Input resistance: 4 kΩ
AO-GND	Analog output 1	0 to 10 V Correction accuracy: 100 mV Resolution: 10 bits Correction accuracy: 1%
T/A-T/C	Normally open terminal	Contact driving capacity: 250 VAC, 3 A, Cos f = 0.4, 30 VDC, 3 A Applies to overvoltage Category II circuit
485+ - 485-	RS485 communication	Half-duplex RS485 communication Max baud rate: 115200 Supporting a maximum of 64 nodes

23 Remove the EMC and VDR screws


If the drive is applied in an IT system, remove the EMC and VDR screws as shown in the following figures.



3 Operating Panel

3.1 Get Familiar with Operating Panel

■ Overview



■ Keys on operation panel

Key	Key Name	Function
	Programming	Enter or exit Level I menu Return to the previous menu
	Confirm	Enter each level of menu interface Confirm displayed parameter setting.
	Increment	When navigating a menu, it moves the selection up through the screens available When editing a parameter value, it increases the displayed value When the AC drive is in RUN mode, it increases the speed
	Decrement	When navigating a menu, it moves the selection down through the screens available When editing a parameter value, it decreases the displayed value When the AC drive is in RUNNING mode, it decreases the speed
	Shift	Select the displayed parameter in the STOP or RUNNING status Select the digit to be modified when modifying a parameter value
	RUN	Start the AC drive when using the operating panel control mode It is inactive when using the terminal or communication control mode
	Stop/Reset	Stop the AC drive when the drive is in the RUNNING status Perform a reset operation when the drive is in the FAULT status Note: The functions of this key can be restricted by using function F7-02.
	Multifunction	Perform a function switchover as defined by the setting of F7-01, for example to quickly switch command source or direction


3 Operating Panel (Keypad & Display)

■ Status Indicators

There are four red LED status indicators at the top of the operating panel

Indicator	Indication
RUN	ON indicates the RUNNING status
	FLASHING indicates power dip ride-through
	OFF indicates the STOP status
REMOTE	ON indicates under terminal control
	FLASHING indicates under remote control
	OFF indicates under operating panel control
FWD/REV	ON indicates reverse motor rotation
	OFF indicates forward motor rotation
TUNE/TC	FLASHING indicates a fault condition on AC drive
	OFF indicates a normal condition on AC drive

■ Operations of Parameters




■ Parameter Arrangement

Function Code Group	Description	Remark
F0 to FF	Standard function code group	Standard function parameters
A1 to AC	Advanced function code group	AI/AO correction
U0	RUNNING status function code group	Display of basic parameters








4 Quick Setup

4.1 Setup Flowchart



Para	Parameter name	Default	Commission
	Install and wire the drive as explained in chapters 1 to 3 of the FIE1N AC Drives User Manual		
	-		
FP-01	Parameter initialization	0	
	0: No operation 01: Restore default settings except motor parameters 02: Clear records including errors 03: Reserved 04: Back up parameters 05 to 19: Reserved 20: Mechanical movement industry (conveying belt) 21: Inertia industry (fan) 22 to 500: Reserved 501: Restore user's backup parameters NOTE: It is recommended to "Restore default settings" prior to commissioning the AC drive		
Para	Parameter name	Default	Commission

START
Set motor parameters

Para	Parameter name	Default	Commission
	Motor Nameplate		
F1-01	Rated motor power	model dependent	15
	Unit: kW		
F1-02	Rated motor voltage	model dependent	380
	Unit: V		
F1-03	Rated motor current	model dependent	34
	Unit: A		
F1-04	Rated motor frequency	model dependent	50
	Unit: Hz		
F1-05	Rated motor speed	model dependent	2800
	Unit: rpm		
F1-37	Auto-tuning selection	0	1
	0: No auto-tuning 1: Static auto-tuning Steps of auto-tuning: 1. Ensure the UVW connection between inverter and motor is not cut off by output contactor; if it is cut off, then manually handle with the output contactor 2. Set F0-02 = 0 (operating panel), so that the key  can start the tuning procedure 3. Set F1-37 = 1, press  , then LED on panel will display letters "TUNE" 4. Press the key  on panel, then motor starts auto-tuning, it usually takes about 30 seconds to finish this auto-tuning, wait until LED stops displaying "TUNE"		
F0-02	Command source selection	1	
	0: Operating panel (keypad & display) 1: Terminal I/O control 2: Serial comms		
F0-03	Main frequency reference setting channel selection	0	
	0: Digital setting F0-08 (pressing  or  can revise F0-08 easily, and the revised value won't be cleared even after power off) 1: Digital setting F0-08 (pressing  or  can change F0-08 easily, but the revised value would be cleared after power off) 2: AI 5: Pulse setting (DI4) 6: Multi-reference setting 7: Simple PLC 8: PID 9: Communication setting		


Perform motor auto-tuning

Select command source

Select frequency reference setting channel

CONTINUE

Para	Parameter name	Default	Commission
------	----------------	---------	------------



Para	Parameter name	Default	Commission
F0-08	Preset frequency	5000	
	0 Hz to F0-10		
F4-13	AI curve minimum input	000	
0 V to F4-15;			
F4-14	Corresponding percentage of AI minimum input	00	
-1000% to 1000%			
F4-15	AI maximum input	1000	
F4-13 to 1000 V			
F4-16	Corresponding percentage of AI maximum input	1000	
-1000% to 1000%			
FC-00	Reference 0	00	
00% to 1000%			
FC-01 to FC-07	Reference 1 to reference 7	00	
00% to 1000%			
F4-00	DI1 function selection	1	
0: No function 1: Forward run (FWD) 2: Reverser run (REV) 3: Three-wire control 4: Forward jog (FJOG) 5: Reverse jog (RJOG) 6: Terminal UP 7: Terminal DOWN 8: Coast to stop 9: Fault reset (RESET) 10: RUN disabled 11: External fault normally-open input 12: Multi-reference terminal 1 13: Multi-reference terminal 2 14: Multi-reference terminal 3 15: Multi-reference terminal 4 16: Terminal 1 for acceleration/deceleration time selection 18: Frequency reference setting channel switchover 19: UP and DOWN setting clear (terminal, operation panel) 20: Command source switchover 21: Acceleration/Deceleration prohibited 22: PID disabled 23: PLC state reset			
Para	Parameter name	Default	Commission

CONTINUE

Para	Parameter name	Default	Commission
F4-00	DI1 function selection	1	
	30: Pulse input as frequency reference (valid only for DI4) 32: Immediate DC injection braking 33: External fault normally-closed input 34: Frequency modification enabled 35: PID operation direction reverse 36: External stop 1 37: Command source switchover 2 38: PID integral disabled 39: Switchover between main frequency reference and preset frequency 40: Switchover between auxiliary frequency reference and preset frequency 43: PID parameter switchover 47: Emergency stop (ES) 48: External stop 2 49: Deceleration DC injection braking 50: Clear running time this time 51: Two-wire control/ Three-wire control 52: Reverse running prohibited		
F4-01	DI2 function selection	4	
	Setting range same as DI1		
F4-02	DI3 function selection	9	
	Setting range same as DI1		
F4-03	DI4 function selection	12	
	Setting range same as DI1		
F5-02	Relay function selection(T/A-T/C)	0	
	0: No output 1: AC drive running 2: Fault output 3: Frequency level detection 1 output 4: Frequency reached 5: Zero-speed running (no output at stop) 6: Motor overload pending 7: AC drive overload pending 11: PLC cycle completed 12: Accumulative running time reached 13: Frequency limited 15: Ready for RUN 17: Frequency upper limit reached 18: Frequency lower limit reached (no output at stop) 19: Undervoltage 20: Communication setting 24: Accumulative power-on time reached 26: Frequency 1 reached 28: Current 1 reached 30: Timing reached		

If any digital output is used

Set DO function

CONTINUE

Para	Parameter name	Default	Commission
------	----------------	---------	------------

CONTINUE	Para	Parameter name	Default	Commission
Set DO function	F5-02	Relay function selection(T/A-T/C)	0	
↓		31: AI input exceeding limit 32: Load lost 33: Reverse running 34: Zero current 36: Output current exceeding limit 37: Frequency lower limit reached (having output at stop) 38: Alarm output 40: Current running time reached 41: Fault output		
If an analog output is used				
Set AO function	F5-07	AO function selection	0	
↓		0: Running frequency 1: Set frequency 2: Output current 3: Output torque 4: Output power 5: Output voltage 6: Pulse input (100% corresponding to 20 kHz) 7: AI 12: Communication setting 13: Motor rotational speed 14: Output current (100% corresponding to 100 A) 15: Output voltage (100% corresponding to 1000 V)		
Set accel /decel time	F0-17	Acceleration time 1	Model dependent	
↓		00s to 65000s		
If smooth accel/decel is requested	F0-18	Deceleration time 1	Model dependent	
↓		00s to 65000s		
Set S-curve	F6-07	Acceleration/Deceleration mode	0	
↓		0: Linear acceleration/deceleration 1: Static S-curve acceleration/deceleration 2: Dynamic S-curve acceleration/deceleration		
↓	F6-08	Time proportion of S-curve at Accel start	300	
↓		00% to (1000% - F6-09)		
↓	F6-09	Time proportion of S-curve at Accel end	300	
↓		00% to (1000% - F6-08)		
CONTINUE	Para			

CONTINUE		Para	Parameter name	Default	Commission	
<div style="border: 1px solid black; padding: 5px; width: fit-content; margin-bottom: 10px;">Set V/F parameters</div> <div style="border-left: 1px solid black; border-right: 1px solid black; height: 300px; margin-bottom: 10px;"></div> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin-bottom: 10px;">Trial RUN</div> <div style="border-left: 1px solid black; border-right: 1px solid black; height: 30px; margin-bottom: 10px;"></div> <div style="border: 1px solid black; padding: 5px; width: fit-content;">Finish</div>	F3-00	V/F curve selection	0			
			0: Linear V/F 1: Multi-point V/F			
	F3-01	Torque boost	00			
			00 to 300 %; NOTE: if it is 0, then auto torque boost is activated, and it is recommended to use auto torque boost			
	F3-02	Frequency limit of torque boost	5000			
			000 Hz to maximum output frequency			
	F3-03	Multi-point V/F frequency 1	000			
			000 Hz to F3-05			
	F3-04	Multi-point V/F voltage 1	00			
			00 to 1000 V			
	F3-05	Multi-point V/F frequency 2	000			
			F3-03 to F3-07, Hz			
	F3-06	Multi-point V/F voltage 2	00			
			00 to 1000 V			
	F3-07	Multi-point V/F frequency 3	000			
			F3-05 to rated motor frequency F1-04, Hz			
F3-08	Multi-point V/F voltage 3	00				
		00 to 1000 V				
		Use operating panel, or digital input terminal, or serial communication control, to start inverter, check if the running performance satisfies your application. If yes, then go forward to next step, if NO, then go back to check				

5. Parameter Table

5.1 Introduction

Groups F and A include standard function parameters. Group U includes the monitoring function parameters and extension card communication parameters.

5.2 Standard Parameters

Para No	Para Name	Setting Range	Default	Comms Address
Group F0: Standard Parameters				
F0-02	Command source selection	0: Operating panel 1: Terminal I/O control 2: Serial comms	0	0xF002/0x0002
F0-03	Main frequency reference setting channel selection	0: Digital setting (non-retentive at power down) 1: Digital setting (retentive at power down) 2: AI 5: Pulse reference(DI4) 6: Multi-reference 7: Simple PLC 8: PID reference 9: Serial comms	0	0xF003/0x0003
F0-04	Auxiliary frequency reference setting channel selection	Same with F0-03	0	0xF004/0x0004
F0-05	Base value of range of auxiliary frequency reference for main and auxiliary calculation	0: Relative to maximum frequency 1: Relative to main frequency reference	0	0xF005/0x0005
F0-06	Range of auxiliary frequency reference for main and auxiliary calculation	0% to 150%	100%	0xF006/0x0006
F0-07	Final Frequency reference setting selection	00 to 34	00	0xF007/0x0007
F0-08	Preset frequency	000 to max frequency (F0-10)	5000 Hz	0xF008/0x0008
F0-09	Running direction	0: Run in the default direction 1: Run in the direction reverse to the default direction	0	0xF009/0x0009
F0-10	Max frequency	5000 to 50000 Hz	5000 Hz	0xF00A/0x000A
F0-11	Setting channel of frequency upper limit	0: Set by F0-12 1: AI 4: Pulse reference (DI4) 5: Communication reference	0	0xF00B/0x000B
F0-12	Frequency reference upper limit	F0-14 to F0-10	5000 Hz	0xF00C/0x000C
F0-14	Frequency reference lower limit	000 Hz to frequency upper limit (F0-12)	000 Hz	0xF00E/0x000E
F0-15	Carrier frequency	08 to 11 kHz	Model dependent	0xF00F/0x000F
F0-16	Carrier frequency adjusted with temperature	0: Disabled 1: Enabled	1	0xF010/0x0010
F0-17	Accelerationtime1	00s to 65000s	Model dependent	0xF011/0x0011
F0-18	Decelerationtime1	00s to 65000s	Model dependent	0xF012/0x0012
F0-23	Retentive of digital setting frequency upon stop	0: Not retentive 1: Retentive	0	0xF017/0x0017

Para No	Para Name	Setting Range	Default	Comms Address
F0-25	Acceleration/Deceleration time base frequency	0: Maximum frequency (F0-10) 1: Frequency reference 2: 100 Hz	0	0xF019/0x0019
F0-26	Base frequency for UP/DOWN modification during running	0: Running frequency 1: Frequency Reference	0	0xF01A/0x001A
Group F1: Motor 1 Parameters				
F1-01	Rated motor power	01 to 37 kW	Model dependent	0xF101/0x0101
F1-02	Rated motor voltage	1 to 600 V	Model dependent	0xF102/0x0102
F1-03	Rated motor current	001 to 15 A	Model dependent	0xF103/0x0103
F1-04	Rated motor frequency	001 Hz to max frequency	Model dependent	0xF104/0x0104
F1-05	Rated motor speed	1 to 65535 rpm	Model dependent	0xF105/0x0105
F1-06	Stator resistance	0.001 to 65.535 Ω	Auto-tuning dependent	0xF106/0x0106
F1-37	Motor auto-tuning method selection	0: No auto-tuning 1: Static auto-tuning 1	0	0xF125/0x0125
GroupF3: V/F Control Parameters				
F3-00	V/F curve setting	0: Linear V/F 1: Multi-point V/F	0	0xF305/0x0305
F3-01	Torque boost	00%: automatic boost 01% to 30%	Model dependent	0xF301/0x0301
F3-02	Cut-off frequency of torque boost	000 Hz to max frequency	5000Hz	0xF302/0x0302
F3-03	Multi-point V/F frequency 1	000 Hz to F3-05	000 Hz	0xF303/0x0303
F3-04	Multi-point V/F voltage 1	00% to 1000%	00%	0xF304/0x0304
F3-05	Multi-point V/F frequency 2	F3-03 to F3-07	000Hz	0xF305/0x0305
F3-06	Multi-point V/F voltage 2	00% to 1000%	00%	0xF306/0x0306
F3-07	Multi-point V/F frequency 3	F3-05 to rated motor frequency(F1-04)	000 Hz	0xF307/0x0307
F3-08	Multi-point V/F voltage 3	00% to 1000%	00%	0xF308/0x0308
F3-09	Slip compensation gain	00% to 2000%	00%	0xF309/0x0309
F3-10	V/F over-excitation gain	0 to 200	64	0xF30A/0x030A
F3-18	Current limit level	50% to 200%	150%	0xF312/0x0312
F3-19	Current limit selection	0: Disabled 1: Enabled	1	0xF313/0x0313
F3-20	Current limit gain	0 to 100	20	0xF314/0x0314
F3-21	Compensation factor of speed multiplying current limit level	0 to 200%	50%	0xF315/0x0315
F3-22	Voltage limit	330 to 390 V	390 V	0xF316/0x0316
F3-23	Voltage limit selection	0: Disabled 1: Enabled	1	0xF318/0x0317
F3-24	Frequency gain for voltage limit	0 to 100	30	0xF318/0x0318
F3-25	Voltage gain for voltage limit	0 to 100	30	0xF319/0x0319
F3-26	Frequency rise threshold during voltage limit	0 to 50 Hz	5Hz	0xF31A/0x031A

5 Parameter Table

Para No	Para Name	Setting Range	Default	Comms Address
Group F4: Input Terminals				
F4-00	DI1 function selection	0: No function 1: Forward run (FWD) 2: Reverser run (REV) 3: Three-wire control 4: Forward jog (FJOG) 5: Reverse jog (RJOG) 6: Terminal UP 7: Terminal DOWN 8: Coast to stop 9: Fault reset (RESET) 10: RUN disabled	1	0xF400/0x0400
F4-01	DI2 function selection	11: External fault normally-open input 12: Multi-reference terminal 1 13: Multi-reference terminal 2 14: Multi-reference terminal 3 15: Multi-reference terminal 4 16: Terminal 1 for acceleration/deceleration time selection 18: Frequency reference setting channel switchover 19: UP and DOWN setting clear (terminal, operation panel) 20: Command source switchover 21: Acceleration/Deceleration prohibited 22: PID disabled	4	0xF401/0x0401
F4-02	DI3 function selection	23: PLC state reset 30: Pulse input as frequency reference (valid only for DI4) 32: Immediate DC injection braking 33: External fault normally-closed input	9	0xF402/0x0402
F4-03	DI4 function selection	34: Frequency modification enabled 35: PID operation direction reverse 36: External stop 1 37: Command source switchover 2 38: PID integral disabled 39: Switchover between main frequency reference and preset frequency 40: Switchover between auxiliary frequency reference and preset frequency 43: PID parameter switchover 47: Emergency stop (ES) 48: External stop 2 49: Deceleration DC injection braking 50: Clear running time this time 51: Two-wire control/ Three-wire control 52: Reverse running prohibited	12	0xF403/0x0403
F4-10	DI filter time	0000s to 1000s	0010s	0xF40A/0x040A
F4-11	Terminal I/O control mode	0: Two-wire control mode 1 1: Two-wire control mode 2 2: Three-wire control mode 1 3: Three-wire control mode 2	0	0xF40B/0x040B
F4-12	Terminal UP/DOWN rate	0001 to 65535 Hz/s	1000 Hz/s	0xF40C/0x040C

Para No	Para Name	Setting Range	Default	Comms Address
F4-13	AI curve1 min input	000 V to F4-15	000 V	0xF40D/0x040D
F4-14	Corresponding percentage of AI curve 1 min input	-10000% to 1000%	00%	0xF40E/0x040E
F4-15	AI curve 1 max input	F4-13 to 1000 V	1000 V	0xF40F/0x040F
F4-16	Corresponding percentage of AI curve1 max input	-10000% to 1000%	1000%	0xF410/0x0410
F4-17	AI filter time	000s to 1000s	010s	0xF411/0x0411
F4-28	Pulse min input	000 kHz to F4-30	000 kHz	0xF41C/0x041C
F4-29	Corresponding percentage of pulse min input	-10000% to 1000%	00%	0xF41D/0x041D
F4-30	Pulse max input	F4-28 to 2000 kHz	5000 kHz	0xF41E/0x041E
F4-31	Corresponding percentage of pulse max input	-10000% to 1000%	1000%	0xF41F/0x041F
F4-32	Pulse filter time	000s to 1000s	010s	0xF420/0x0420
F4-38	DI active mode selection1	00000 to 11111	00000	0xF426/0x0426
Group F5: Output Terminals				
F5-02	Relay (T/A-T/B-T/C) function selection	0: No output 1: AC drive running 2: Fault output 3: Frequency level detection 1 output 4: Frequency reached 5: Zero-speed running (no output at stop) 6: Motor overload pending 7: AC drive overload pending 11: PLC cycle completed 12: Accumulative running time reached 13: Frequency limited 15: Ready for RUN 17: Frequency upper limit reached 18: Frequency lower limit reached (no output at stop)	2	0xF502/0x0502
F5-02	Relay (T/A-T/B-T/C) function selection	19: Undervoltage 20: Communication setting 24: Accumulative power-on time reached 26: Frequency 1 reached 28: Current 1 reached 30: Timing reached 31: AI input exceeding limit 32: Load lost 33: Reverse running 34: Zero current 36: Output current exceeding limit 37: Frequency lower limit reached (having output at stop) 38: Alarm output 40: Current running time reached 41: Fault output	2	0xF502/0x0502

5 Parameter Table

Para No	Para Name	Setting Range	Default	Comms Address
F5-07	AO1functionselection	0: Running frequency 1: Frequency reference 2: Output current 3: Output torque 4: Output power 5: Output voltage 6: Pulse input 7: AI 12: Communication reference 13: Motor speed 14: Output current 15: Output voltage	0	0xF507/0x0507
F5-10	AO zero offset coefficient	-1000% to 1000%	00%	0xF50A/0x050A
F5-11	AO gain	-1000 to 1000	100	0xF50B/0x050B
F5-18	Relay1outputdelay	00s to 36000s	00s	0xF512/0x0512
F5-22	DO active mode selection 1	00000 to 11111	00000	0xF516/0x0516
Group F6: Start/Stop Control				
F6-00	Start mode	0: Direct start 1: Catching a spinning motor	0	0xF600/0x0600
F6-01	Mode of catching a spinning motor	0: From stop frequency 1: From zero speed 2: From max frequency 4: Catching a spinning motor in field-orientated control (requiring static auto-tuning, F1-37 = 1)	4	0xF601/0x0601
F6-03	Start frequency	000to1000Hz	000 Hz	0xF603/0x0603
F6-04	Start frequency holding time	00s to 1000s	00s	0xF604/0x0604
F6-07	Acceleration/Deceleration mode	0: Linear acceleration/deceleration 1: Static S-curve acceleration/deceleration 2: Dynamic S-curve acceleration/deceleration	0	0xF607/0x0607
F6-08	Time proportion of S-curve start segment	00% to (1000% -F6-09)	300%	0xF608/0x0608
F6-09	Time proportion of S-curve end segment	00% to (1000% -F6-08)	300%	0xF609/0x0609
F6-10	Stop mode	0: Decelerate to stop 1: Coast to stop	0	0xF60A/0x060A
F6-11	DC injection braking 2 start frequency	000 Hz to maximum frequency	000 Hz	0xF60B/0x060B
F6-12	DC injection braking 2 delay time	00 to 1000s	00s	0xF60C/0x060C
F6-13	DC injection braking 2 level	0% to 100%	50%	0xF60D/0x060D
F6-14	DC injection braking 2 active time	00s to 1000s	00s	0xF60E/0x060E
F6-21	Demagnetization time	000s to 500s	05s	0xF615/0x0615
F6-22	Min output frequency	000 Hz to F6-11	000 Hz	0xF616/0x0616

Para No	Para Name	Setting Range	Default	Comms Address
Group F7: Keypad Operation and LED Display				
F7-00	LED default display check	0: Disabled 1: Enabled	0	0xF700/0x0700
F7-01	MFk key function selection	0: MFk key disabled 1: Switchover from remote control (terminal or communication) to keypad control 2: Switchover between forward rotation and reverse rotation 3: Forward jog 4: Reverse jog 5: Parameter display mode switchover	0	0xF701/0x0701
F7-06	Load speed display coefficient	00001 to 65000	10000	0xF706/0x0706
F7-07	Heatsink temperature of IGBT	0°C to 100°C	-	0xF707/0x0707
F7-08	Product series	200	-	0xF708/0x0708
F7-09	Accumulative running time	0 to 65535h	-	0xF709/0x0709
F7-10	Performance software version	-	-	0xF70A/0x070A
F7-11	Function software version	-	-	0xF70B/0x070B
F7-12	Number of decimal places for load speed display	10 to 23	21	0xF70C/0x070C
F7-13	Accumulative power-on time	0 to 65535 h	-	0xF70D/0x070D
F7-14	Accumulative power consumption	0 to 65535 kWh	-	0xF70E/0x070E
Group F8: Auxiliary Functions				
F8-00	Jog frequency reference	000 Hz to max frequency	200Hz	0xF800/0x0800
F8-01	Jog acceleration time	00s to 65000s	200s	0xF801/0x0801
F8-02	Jog deceleration time	00s to 65000s	200s	0xF802/0x0802
F8-03	Acceleration time 2	00s to 65000s	Model dependent	0xF803/0x0803
F8-04	Deceleration time 2	00s to 65000s	Model dependent	0xF804/0x0804
F8-12	Forward/Reverse run switchover dead-zone time	00s to 30000s	00s	0xF80C/0x080C
F8-13	Reverse RUN selection	0: Disabled 1: Enabled	0	0xF80D/0x080D
F8-14	Running mode when frequency reference lower than frequency lower limit	0: Run at frequency reference lower limit 1: Stop 2: Run at zero speed	0	0xF80E/0x080E
F8-16	Accumulative power-on time threshold	0 to 65000 h	0h	0xF810/0x0810
F8-17	Accumulative running time threshold	0 to 65000 h	0h	0xF811/0x0811
F8-18	Startup protection selection	0: Disabled 1: Enabled	0	0xF812/0x0812
F8-19	Frequency detection value 1	000 Hz to max frequency	5000 Hz	0xF813/0x0813
F8-20	Frequency detection hysteresis 1	00% to 1000%	50%	0xF814/0x0814
F8-21	Detection width of target frequency reached	00% to 1000%	00%	0xF815/0x0815
F8-25	Switchover frequency of accel time 1 and accel time 2	000 Hz to max frequency	000 Hz	0xF819/0x0819

5 Parameter Table

Para No	Para Name	Setting Range	Default	Comms Address
F8-26	Switchover frequency of decel time 1 and decel time 2	000 Hz to max frequency	000 Hz	0xF81A/0x081A
F8-27	Set highest priority to terminal JOG function	0: Disabled 1: Enabled	0	0xF81B/0x081B
F8-30	Detection of frequency1	000 Hz to max frequency	5000 Hz	0xF81E/0x081E
F8-31	Detection width of frequency1	00% to 1000% (max frequency)	00%	0xF81F/0x081F
F8-34	Zero current detection level	00% to 3000% (rated motor current)	50%	0xF822/0x0822
F8-35	Zero current detection delay	001s to 60000s	0.10s	0xF823/0x0823
F8-36	Output overcurrent threshold	00% (no detection) 0.1% to 3000% (rated motor current)	2000%	0xF824/0x0824
F8-37	Output overcurrent detection delay	000s to 60000s	000s	0xF825/0x0825
F8-38	Detection level of current1	00% to 3000% (rated motor current)	1000%	0xF826/0x0826
F8-39	Detection width of current1	00% to 3000% (rated motor current)	00%	0xF827/0x0827
F8-42	Timing function	0: Disabled 1: Enabled	0	0xF82A/0x082A
F8-43	Running time setting channel	0: Set by F8-44 1: AI	0	0xF82B/0x082B
F8-44	Running time	00 to 65000 min	00 min	0xF82C/0x082C
F8-45	AI input voltage lower limit	000 V to F8-46	310 V	0xF82D/0x082D
F8-46	AI input voltage upper limit	F8-45 to 1000 V	680 V	0xF82E/0x082E
F8-53	Running time threshold this time	00 to 65000 min	00 min	0xF835/0x0835
F8-54	Output power correction coefficient	00% to 2000%	1000%	0xF836/0x0836
F8-55	Emergency deceleration time	00s to 65000s	0.1s	0xF837/0x0837
F8-57	Speed synchronous control selection	0: Disabled 1: Enabled	0	0xF839/0x0839
<p>It selects whether to enable the speed synchronous control function This function means direction data communication between two or more AC drives via CANlink, implementing target frequency of one or more slaves to be synchronized to that of the master When this function is enabled, CANlink communication addresses of the master and slaves are matched automatically The baud rate in speed synchronous control is set in Fd-00</p>				
F8-58	Master and slave selection in synchronous control	0: Master 1: Slave	0	0xF83A/0x083A
<p>It is used to select whether the AC drive is master or slave When the AC drive is slave, set F0-03 = 9 to set frequency reference via communication</p>				
Group F9: Fault and Protection				
F9-00	Motor overload protection	0: Disabled 1: Enabled	1	0xF900/0x0900
F9-01	Motor overload protection gain	020 to 1000	020	0xF901/0x0901
F9-02	Motor overload pre-warning coefficient	50% to 100%	80%	0xF902/0x0902
F9-07	Detection of short-circuit to ground upon power-on	0: Disabled 1: Enabled	1	0xF907/0x0907
F9-08	Braking unit applied voltage	310 to 400 V	378 V	0xF908/0x0908
F9-09	Auto reset times	0 to 20	0	0xF909/0x0909


Para No	Para Name	Setting Range	Default	Comms Address
F9-10	Selection of DO action during auto reset	0: Not act 1: Act	0	0xF90A/0x090A
F9-11	Delay of auto reset	0.1s to 1000s	10s	0xF90B/0x090B
F9-13	Output phase loss protection	0: Disabled 1: Enabled	1	0xF90D/0x090D
F9-14	1st fault type	0: No fault	-	0xF90E/0x090E
F9-15	2nd fault type	1: Reserved	-	0xF90F/0x090F
F9-16	3rd (latest) fault type	2: Overcurrent during acceleration 3: Overcurrent during deceleration 4: Overcurrent at constant speed 5: Overvoltage during acceleration 6: Overvoltage during deceleration 7: Overvoltage at constant speed 8: Pre-charge resistor overloaded 9: Undervoltage 10: AC drive overloaded 11: Motor overloaded 12: Input phase loss 13: Output phase loss 14: IGBT overheat 15: External fault 16: Communication abnormal 17: Reserved 18: Current detection abnormal 19: Motor auto-tuning abnormal 20: Reserved 21: Parameter read-write abnormal 22: Reserved 23: Motor short circuited to ground 24: Reserved 25: Reserved 26: Accumulative running time reached 29: Accumulative power-on time reached 30: Load lost 31: PID feedback lost during running 40: Overcurrent fast prevention timeout 41: Reserved 42: Reserved 43: Reserved 45: Reserved 51: Reserved 55: Slave fault in speed synchronous	-	0xF910/0x0910
F9-17	Frequency upon 3rd fault	-	-	0xF911/0x0911
F9-18	Current upon 3rd fault	-	-	0xF912/0x0912
F9-19	Bus voltage upon 3rd fault	-	-	0xF913/0x0913
F9-20	DI state upon 3rd fault	-	-	0xF914/0x0914
F9-21	DO state upon 3rd fault	-	-	0xF915/0x0915
F9-22	AC drive state upon 3rd fault	-	-	0xF916/0x0916
F9-23	Power-on time upon 3rd fault	-	-	0xF917/0x0917
F9-24	Running time upon 3rd fault	-	-	0xF918/0x0918


5 Parameter Table

Para No	Para Name	Setting Range	Default	Comms Address
F9-27	Frequency upon 2nd fault	-	-	0xF91B/0x081B
F9-28	Current upon 2nd fault	-	-	0xF91C/0x091C
F9-29	Bus voltage upon 2nd fault	-	-	0xF91D/0x091D
F9-30	DI state upon 2nd fault	-	-	0xF91E/0x091E
F9-31	DO state upon 2nd fault	-	-	0xF91F/0x091F
F9-32	AC drive state upon 2nd fault	-	-	0xF920/0x0920
F9-33	Power-on time upon 2nd fault	-	-	0xF921/0x0921
F9-34	Running time upon 2nd fault	-	-	0xF922/0x0922
F9-37	Frequency upon 1st fault	-	-	0xF925/0x0925
F9-38	Current upon 1st fault	-	-	0xF926/0x0926
F9-39	Bus voltage upon 1st fault	-	-	0xF927/0x0927
F9-40	DI state upon 1st fault	-	-	0xF928/0x0928
F9-41	DO state upon 1st fault	-	-	0xF929/0x0929
F9-42	AC drive state upon 1st fault	-	-	0xF92A/0x092A
F9-43	Power-on time upon 1st fault	-	-	0xF92B/0x092B
F9-44	Running time upon 1st fault	-	-	0xF92C/0x092C
F9-47	Fault protection action selection 1	00000 to 22222	00000	0xF92F/0x092F
F9-48	Fault protection action selection 2	00000 to 11111	00000	0xF930/0x0930
F9-49	Fault protection action selection 3	00000 to 22222	00000	0xF931/0x0931
F9-54	Frequency selection for continuing to run upon fault	0: Current running frequency 1: Frequency reference 2: Frequency upper limit 3: Frequency lower limit 4: Backup frequency upon abnormality	0	0xF936/0x0936
F9-55	Backup frequency upon fault	00% to 1000% (max frequency)	1000%	0xF937/0x0937
F9-59	Power dip ride-through function selection	0: Disabled 1: Bus voltage constant control 2: Decelerate to stop	0	0xF93B/0x093B
F9-60	Threshold of power dip ride-through function disabled	80% to F9-60	85%	0xF93C/0x093C
F9-61	Judging time of bus voltage recovering from power dip	00s to 1000s	05s	0xF93D/0x093D
F9-62	Threshold of power dip ride-through function enabled	60% to 100%	80%	0xF93E/0x093E
F9-63	Load lost protection	0: Disabled 1: Enabled	0	0xF93F/0x093F
F9-64	Load lost detection level	00% to 1000%	100%	0xF940/0x0940
F9-65	Load lost detection time	00s to 600s	10s	0xF941/0x0941
F9-71	Power dip ride-through gain Kp	0 to 100	40	0xF947/0x0947
F9-72	Power dip ride-through integral coefficient	0 to 100	30	0xF948/0x0948
F9-73	Deceleration time of power dip ride-through	00s to 3000s	200s	0xF949/0x0949
F9-74	Restart mode after fault reset	0: Normal 1: Catching a spinning motor	0	0xF94A/0x094A


Para No	Para Name	Setting Range	Default	Comms Address
Group FA: PID Function				
FA-00	PID reference setting channel	0: Set by FA-01 1: AI 4: Pulse reference (DI4) 5: Via communication 6: Multi-reference	0	0xFA00/0x0A00
FA-01	PID digital setting	00% to 1000%	500%	0xFA01/0x0A01
FA-02	PID feedback setting channel	0: AI 4: PULSE reference (DI4) 5: Via communication	0	0xFA02/0x0A02
FA-03	PID operation direction	0: Forward 1: Reverse	0	0xFA03/0x0A03
FA-04	PID reference and feedback range	0 to 65535	1000	0xFA04/0x0A04
FA-05	Proportional gain Kp1	00 to 10000	200	0xFA05/0x0A05
FA-06	Integral time Ti1	001s to 1000s	200s	0xFA06/0x0A06
FA-07	Differential time Td1	0000s to 10000s	0000s	0xFA07/0x0A07
FA-08	PID output limit in reverse direction	000 Hz to max frequency	000Hz	0xFA08/0x0A08
FA-09	PID error limit	00% to 1000%	00%	0xFA09/0x0A09
FA-10	PID differential limit	000% to 10000%	010%	0xFA0A/0x0A0A
FA-11	PID reference change time	000s to 65000s	000s	0xFA0B/0x0A0B
FA-12	PID feedback filter time	000s to 6000s	000s	0xFA0C/0x0A0C
FA-13	PID output filter time	000s to 6000s	000s	0xFA0D/0x0A0D
FA-15	Proportional gain Kp2	00 to 10000	200	0xFA0F/0x0A0F
FA-16	Integral time Ti2	001s to 1000s	200s	0xFA10/0x0A10
FA-17	Differential time Td2	0000s to 10000s	0000s	0xFA11/0x0A11
FA-18	PID parameter switchover condition	0: Not switched over 1: Switched over via DI 2: Switched over automatically according to error 3: Switched over automatically according to running frequency	0	0xFA12/0x0A12
FA-19	PID error 1 for auto switchover	00% to FA-20	200%	0xFA13/0x0A13
FA-20	PID error 2 for auto switchover	FA-19 to 1000%	800%	0xFA14/0x0A14
FA-21	PID initial value	00% to 1000%	00%	0xFA15/0x0A15
FA-22	PID initial value active time	000s to 65000s	000s	0xFA16/0x0A16
FA-23	Max value of two outputs error in forward direction	000% to 10000%	100%	0xFA17/0x0A17
FA-24	Max value of two outputs error in reverse direction	000% to 10000%	100%	0xFA18/0x0A18
FA-25	PID integral property	00 to 11	00	0xFA19/0x0A19
FA-26	Detection level of PID feedback loss	0%: No detection 01% to 1000%	00%	0xFA1A/0x0A1A
FA-27	Detection time of PID feedback loss	00s to 200s	00s	0xFA1B/0x0A1B
FA-28	Selection of PID operation at stop	0: Disabled 1: Enabled	0	0xFA1C/0x0A1C

5 Parameter Table

Para No	Para Name	Setting Range	Default	Comms Address
Group FC: Multi-Reference and Simple PLC Function				
FC-00	Reference0	-1000% to 1000%	00%	0xFC00/0x0C00
FC-01	Reference1	-1000% to 1000%	00%	0xFC01/0x0C01
FC-02	Reference2	-1000% to 1000%	00%	0xFC02/0x0C02
FC-03	Reference3	-1000% to 1000%	00%	0xFC03/0x0C03
FC-04	Reference4	-1000% to 1000%	00%	0xFC04/0x0C04
FC-05	Reference5	-1000% to 1000%	00%	0xFC05/0x0C05
FC-06	Reference6	-1000% to 1000%	00%	0xFC06/0x0C06
FC-07	Reference7	-1000% to 1000%	00%	0xFC07/0x0C07
FC-16	Simple PLC running mode	0: Stop after running one cycle 1: Keep final values after running one cycle 2: Repeat after running one cycle	0	0xFC10/0x0C10
FC-17	Simple PLC retentive selection	 <p>Retentive selection at power down 0: Not retentive 1: Retentive</p> <p>Retentive selection at stop 0: Not retentive 1: Retentive</p>	00	0xFC11/0x0C11
FC-18	Running time of simple PLC reference 0	00s (h) to 65000s (h)	00s (h)	0xFC12/0x0C12
FC-19	Acceleration/deceleration time of simple PLC reference 0	0 to 1	0	0xFC13/0x0C13
FC-20	Running time of simple PLC reference 1	00s (h) to 65000s (h)	00s (h)	0xFC14/0x0C14
FC-21	Acceleration/deceleration time of simple PLC reference 1	0 to 1	0	0xFC15/0x0C15
FC-22	Running time of simple PLC reference 2	00s (h) to 65000s (h)	00s (h)	0xFC16/0x0C16
FC-23	Acceleration/deceleration time of simple PLC reference 2	0 to 1	0	0xFC17/0x0C17
FC-24	Running time of simple PLC reference 3	00s (h) to 65000s (h)	00s (h)	0xFC18/0x0C18
FC-25	Acceleration/deceleration time of simple PLC reference 3	0 to 1	0	0xFC19/0x0C19
FC-26	Running time of simple PLC reference 4	00s (h) to 65000s (h)	00s (h)	0xFC1A/0x0C1A
FC-27	Acceleration/deceleration time of simple PLC reference 4	0 to 1	0	0xFC1B/0x0C1B
FC-28	Running time of simple PLC reference 5	00s (h) to 65000s (h)	00s (h)	0xFC1C/0x0C1C
FC-29	Acceleration/deceleration time of simple PLC reference 5	0 to 1	0	0xFC1D/0x0C1D
FC-30	Running time of simple PLC reference 6	00s (h) to 65000s (h)	00s (h)	0xFC1E/0x0C1E
FC-31	Acceleration/deceleration time of simple PLC reference 6	0 to 1	0	0xFC1F/0x0C1F
FC-32	Running time of simple PLC reference 7	00s (h) to 65000s (h)	00s (h)	0xFC20/0x0C20

Para No	Para Name	Setting Range	Default	Comms Address
FC-33	Acceleration/deceleration time of simple PLC reference 7	0 to 1	0	0xFC21/0x0C21
FC-50	Time unit of simple PLC running	0: s 1: h	0	0xFC32/0x0C32
FC-51	Reference 0 source	0: Set by FC-00 1: AI 4: PULSE reference 5: PID 6: Set by F0-08 and modified via UP/DOWN	0	0xFC33/0x0C33
Group Fd: Communication				
Fd-00	Baud rate	0000 to 5009	5005	0xFD00/0x0D00
Fd-01	Data format symbol	0: No check (8-N-2) 1: Even parity check (8-E-1) 2: Odd parity check (8-O-1) 3: No check (8-N-1) (Valid for Modbus)	0	0xFD01/0x0D01
Fd-02	Local address	0: Broadcast address 1 to 247	1	0xFD02/0x0D02
Fd-03	Response delay	0 to 20ms	2	0xFD03/0x0D03
Fd-04	Communication timeout	00: invalid 01s to 600s	00s	0xFD04/0x0D04
Fd-05	Modbus protocol selection and PROFIBUS-DP data frame	0: Non-standard Modbus protocol 1: Standard Modbus protocol	1	0xFD05/0x0D05
Fd-07	PC software selection	0: Disabled 1: Enabled	1	0xFD07/0x0D07
Group FF: Manufacturer Parameters, Access Denied				
Group FP: Function Parameter Management				
FP-00	User password	0 to 65535	0	0x1F00
FP-01	Industry macro	0: No operation 01: Restore factory parameters except motor parameters 02: Clear records 03: Reserved 04: Back up current user parameters 05 to 19: Reserved 20: Mechanical movement industry (conveying belt) 21: Inertia industry (fan) 22 to 500: Reserved 501: Restore user backup parameters	0	0x1F01
FP-02	Parameter display property		11	0x1F02
FP-04	Parameter modification property	0: Modifiable 1: Unmodifiable	0	0x1F04

5 Parameter Table


Para No	Para Name	Setting Range	Default	Comms Address
Group A1: Virtual DI/DO				
A1-07	Function selection for AI used as DI	Same as F4-00	0	0xA107/0x4107
A1-10	Active state selection for AI used as DI		0	0xA10A/0x410A
GroupA5: Control Optimization				
A5-00	DPWM switchover frequency upper limit	500 Hz to max frequency	800Hz	0xA500/0x4500
A5-03	Random PWM depth	0 to 10	0	0xA503/0x4503
A5-04	Overcurrent fast prevention	0: Disabled 1: Enabled	1	0xA504/0x4504
A5-05	Max. output voltage coefficient	100% to 110%	103%	0xA505/0x4505
A5-06	Undervoltage threshold	140 to 280 V	200V	0xA600/0x4600
Group AC: AI/AO Correction				
AC-00	AI measured voltage 1	-1000 to 10000 V	Factory-corrected	0xAC00/0x4C00
AC-01	AI displayed voltage 1	-1000 to 10000 V	Factory-corrected	0xAC01/0x4C01
AC-02	AI measured voltage 2	-1000 to 10000 V	Factory-corrected	0xAC02/0x4C02
AC-03	AI displayed voltage 2	-1000 to 10000 V	Factory-corrected	0xAC03/0x4C03
AC-12	AO target voltage 1	-1000 to 10000 V	Factory-corrected	0xAC0C/0x4C0C
AC-13	AO measured voltage 1	-1000 to 10000 V	Factory-corrected	0xAC0D/0x4C0D
AC-14	AO target voltage 2	-1000 to 10000 V	Factory-corrected	0xAC0E/0x4C0E
AC-15	AO measured voltage 2	-1000 to 10000 V	Factory-corrected	0xAC0F/0x4C0F
Note: Parameters in groups A1 and A5 are not displayed by default They can be displayed by setting FP-02				

53 Monitoring Function Code

Para No	Para Name	Comms Address
Group U0: Monitoring Parameters		
U0-00	Running frequency	0x7000
U0-01	Frequency reference	0x7001
U0-02	Bus voltage	0x7002
U0-03	Output voltage	0x7003
U0-04	Output current	0x7004
U0-05	Output power	0x7005
U0-07	DI state	0x7007
U0-08	DO state	0x7008
U0-09	AI voltage	0x7009
U0-10	Communication protocol	0x700A
U0-14	Load speed display	0x700E
U0-15	PID reference	0x700F
U0-16	PID feedback	0x7010
U0-17	PLC stage	0x7011
U0-18	Pulse reference	0x7012
U0-19	Feedback speed	0x7013
U0-20	Remaining running time	0x7014
U0-21	AI voltage before correction	0x7015
U0-24	Motor speed	0x7018
U0-25	Accumulative power-on time	0x7019
U0-26	Accumulative running time	0x701A
U0-27	Pulse reference	0x701B
U0-28	Communication reference	0x701C
U0-30	Main frequency reference	0x701E
U0-31	Auxiliary frequency reference	0x701F
U0-32	Viewing any register address value	0x7020
U0-37	Power factor angle	0x7025
U0-41	DI state display	0x7029
U0-42	DO state display	0x702A
U0-45	Fault information	0x702D
U0-59	Frequency Reference	0x703B
U0-60	Running frequency	0x703C
U0-61	AC drive state	0x703D
U0-62	Current fault code	0x703E
U0-64	Number of slaves	0x7040

6. Troubleshooting

6.1 AC Drive Performance Fine Tuning



Stage	Symptom	Diagnostics	Remedies
Start	Rollback	Start frequency is too low	Increase F6-03, ranging 0 to 10 Hz
		Torque output is insufficient	Make sure F3-00 = 0, F3-01 = 0
	Starting jerk	Start frequency is too high	Decrease F6-03, ranging 0 to 10 Hz
Acceleration	Jerk when acceleration starts	Too fast acceleration at this section	Increase F6-08, ranging 0 to $(100-(F6-09))\%$ Or increase F0-17, ranging 0 to 6500s
	Jerk when acceleration end	Too fast acceleration at this section	Increase F6-09, ranging 0 to $(100-(F6-08))\%$ Or increase F0-17, ranging 0 to 6500s
	Vibration	Overcurrent stall prevention occurs	It reaches current limit
Nominal speed	Vibration	Too big current loop PI gains	Double check the motor parameters and then perform motor auto-tuning once more
Deceleration	Vibration	Overcurrent stall prevention occurs	it reaches current limit
Stop	Jerk	Too strong DC injection at stop	Decrease F6-13, ranging 0 to 100%
	Slip	Too short DC injection active time at stop	Increase F6-14, ranging 0 to 100s
		Too weak DC injection at stop	Increase F6-13, ranging 0 to 100%
		Braking device applies too late	check the timing of braking device

62 Fault Codes and Troubleshooting

Display	Fault Name	Possible Causes	Solutions
Err02	Overcurrent during acceleration	Ground fault or short circuit exists in the output circuit†	Check whether short-circuit occurs on the motor, the motor cable or contactor†
		Acceleration time is too short†	Increase acceleration time†
		Customized torque boost or V/F curve is not appropriate†	Adjust the customized torque boost or V/F curve†
		The voltage is too low†	Adjust the voltage to normal range†
		The spinning motor is started†	Enable the catching a spinning motor function or start the motor after it stops†
		A load is added suddenly during acceleration†	Cancel the suddenly added load†
		The AC drive power class is small† The braking resistor resistance is small† The braking resistor is short circuited†	Replace a drive of larger power class† Replace a new braking resistor†
Err03	Overcurrent during deceleration	Ground fault or short circuit exists in the output circuit†	Check whether short-circuit occurs on motor, motor cable or contactor†
		Acceleration time is too short†	Increase acceleration time†
		The voltage is too low†	Adjust the voltage to normal range†
		A load is added suddenly during deceleration†	Cancel the suddenly added load†
		Braking unit and braking resistor are not installed†	Install braking unit and braking resistor†
		The braking resistor resistance is small† The braking resistor is short circuited†	Replace a new braking resistor†
Err04	Overcurrent at constant speed	Ground fault or short circuit exists in the output circuit†	Check whether short-circuit occurs on the motor, motor cable or contactor†
		The voltage is too low†	Adjust the voltage to normal range†
		A load is added suddenly during running†	Cancel the suddenly added load†
		The AC drive power class is small†	Replace a drive of larger power class†
		The braking resistor resistance is small† The braking resistor is short circuited†	Replace a new braking resistor†
Err05	Overvoltage during acceleration	Input voltage is too high†	Adjust input voltage to normal range†
		An external force drives motor during acceleration†	Cancel the external force†
		Braking unit and braking resistor are not installed†	Install braking unit and braking resistor†
		Acceleration time is too short†	Increase acceleration time†
Err06	Overvoltage during deceleration	Input voltage is too high†	Adjust input voltage to normal range†
		An external force drives motor during deceleration†	Cancel the external force or install braking resistor†
		Deceleration time is too short†	Increase deceleration time†
		Braking unit and braking resistor are not installed†	Install braking unit and braking resistor†
Err07	Overvoltage at constant speed	Input voltage is too high†	Adjust input voltage to normal range†
		An external force drives motor during running†	Cancel the external force or install a braking resistor†
Err08	Control power fault	Input voltage is not within the permissible range†	Adjust the input voltage in the permissible range†

Display	Fault Name	Possible Causes	Solutions
Err09	Undervoltage	Instantaneous power failure occurs	Reset the fault
		The AC drive's input voltage is not within the permissible range	Adjust the voltage to normal range
		The bus voltage is abnormal	Replace the AC drive
		The rectifier bridge, the pre-charge resistor, the drive board or the control board are abnormal	Replace the AC drive
Err 10	Drive overload	Load is too heavy or locked-rotor occurs on motor	Reduce load or check motor and mechanical conditions
		The AC drive power class is small	Replace a drive of larger power class
Err 11	Motor overload	F9-01 (Motor overload protection gain) is set improperly	Set F9-01 correctly
		Load is too heavy or locked-rotor occurs on motor	Reduce load or check motor and mechanical conditions
		The AC drive power class is small	Replace a drive of larger power class
Err 13	Output phase loss	Motor winding is damaged	Check resistance between motor wires Replace motor is winding is damaged
		The cable connecting the AC drive and the motor is abnormal	Check for wiring errors and ensure the output cable is connected properly
		The AC drive's three-phase outputs are unbalanced when the motor is running	Check whether the motor three-phase winding is normal
		The drive board or the IGBT is abnormal	Replace the AC drive
Err 14	IGBT overheat	The ambient temperature is too high	Lower the ambient temperature
		The ventilation is clogged	Clean the ventilation
		The fan is damaged	Replace the cooling fan
		Thermally sensitive resistor of IGBT is damaged	Replace the AC drive
		The inverter IGBT is damaged	Replace the AC drive
Err 15	External equipment fault	External fault signal is input via DI	Confirm that the mechanical condition allows restart (F8-18) and reset the operation
		External fault signal is input via virtual I/O	Confirm that the virtual I/O parameters in group A1 are set correctly and reset the operation
Err 16	Communication fault	Host computer is in abnormal state	Check the cable of host computer
		Communication cable is abnormal	Check the communication cables
		Communication parameters in group Fd are set improperly	Set communication parameters in group Fd properly
		After all the preceding checkings are done but the fault still exists, restore the default settings	
Err 18	Current detection fault	The drive board is abnormal	Replace the AC drive
Err21	EEPROM read-write fault	EEPROM chip is damaged	Replace the AC drive

Display	Fault Name	Possible Causes	Solutions
Err23	Short circuit to ground	Motor is short circuited to the ground	Replace cable or motor
		Top tube of the inverter is damaged Ask professional to check	Replace the AC drive
Err26	Accumulative running time reached	Accumulative running time reaches the setting value	Clear the record through parameter initialization
Err27	User-defined fault 1	User-defined fault 1 is input via DI.	Reset the operation
		User-defined fault 1 is input via virtual I/O.	
Err28	User-defined fault 2	User-defined fault 2 is input via DI.	Reset the operation
		User-defined fault 2 is input via virtual I/O.	
Err29	Accumulative power-on time reached	Accumulative power-on time reaches the setting value	Clear the record through parameter initialization
Err30	Off load fault	The output current of AC drive is smaller than F9-64 (load loss detection level)	Check whether load is disconnected or the setting of F9-64 and F9-65 (load lost detection time) satisfies actual running condition.
Err31	PID feedback lost during running	PID feedback is smaller than the setting value of FA-26 (detection level of PID feedback loss)	Check PID feedback or set FA-26 properly
Err40	Quick current limit	Load is too heavy or locked-rotor occurs on motor	Reduce load or check motor and mechanical conditions
		The AC drive power class is small	Replace a drive of larger power class
Err55	Slave faulty in speed synchronous	When speed synchronous is enabled, the master receives CAN communication data but does not detect the slave Then Err55 is reported	1 Check the slave CAN communication cable connection 2 Check whether CAN communication of the slave is normal

63 Symptoms and Diagnostics

Fault Name	Possible Causes	Solutions
There is no display at power-on	The mains voltage is not input or too low	Check the power supply
	The AC Drive is damaged	Replace the AC drive
HC is displayed at power-on	Wire between drive board and control board is in poor contact	Re-connect the 4-pin wire and 28-pin wire
	Control board is damaged	Replace the AC drive
	The motor or motor cable is short circuited to ground	Check whether short-circuit occurs on motor, motor cable or contactor
	The mains voltage is too low	Check the power supply
	The mains voltage is too low	
Err 14 (IGBT overheat) is detected frequently	The setting of carrier frequency is too high	Reduce carrier frequency (F0-15)
	The cooling fan is damaged, or ventilation is clogged	Replace the fan or clean the ventilation
	Components inside the AC drive are damaged (thermistor or others)	Replace the AC drive
The motor does not rotate after the AC drive runs	It is motor or motor cable problem	Check that wiring between AC drive and motor is normal
	Related AC drive and motor parameters are set improperly	Restore the factory parameters and re-set the motor parameters properly
	The drive board is faulty	Replace the AC drive
The DI terminals are disabled	Related parameters are set incorrectly	Check and set parameters in group F4 again
	External signals are incorrect	Re-connect external signal cables
	The control board is damaged	Replace the AC drive
The AC drive detects overcurrent and overvoltage frequently	Motor parameters are set improperly	Set motor parameters or perform motor auto-tuning again
	Acceleration/deceleration time is improper	Set proper acceleration/deceleration time
	Load fluctuates.	Contact the agent or VTdrive

Revision History

Revision	Date	Description
V00	January 24, 2016	Related firmware version: F7-10 = U10.05 and F7-11 = U0.06
A01	March 22, 2016	Related firmware version: F7-10 = U10.06 and F7-11 = 001.00

VTdrive Technology Limited

Address: 6F, Xinfeng Building B, Yangguang Industrial Zone, Xili Town, Nanshan District, Shenzhen, China.

Postal Code: 518055

Tel: 0755 - 23060667

Fax: 0755 - 33671802

Website: www.vtdrive.com

E-mail: info@vtdrive.com

English version: FIE1N (BOM: 37220077) printed for the first time.

This document is subject to change without notice.

All rights reserved. Any unauthorized reproduction or copy is forbidden.